

SYSTEM CHART

ROCKCOTE RENDER SYSTEM for Fibre Cement Sheet

Surface Preparation

Remove all deleterious and loose materials and leave surfaces clean and free of dust, oil, dirt, mould or any other contamination.

Joints

Patch, tape and set all recessed joints with 5 parts Rockcote Hard Patch mixed with 1 part Cement by volume and 120gsm Non Adhesive Mesh Tape or alternatively set joints with Rockcote Patch & Prep.

Colour

Only colours with a Light Reflectance Value of 40% or higher are suitable for use over fibre cement sheeting.

Please refer to the relevant Technical Specification & Material Safety Data Sheet before application.

PERFORMANCE CODE 5

Finish	1st Step (set joints)	2nd Step	3rd Step	4th Step	5th Step
Armour Flex	Hard Patch or Patch & Prep	Polymer Render	Polymer Render	Armour Flex (stipple)	Armour Flex (long nap roller)
Finecote	Hard Patch or Patch & Prep	Polymer Render	1mm Finecote *	Armour Plus	Armour Plus
Quicksand	Hard Patch or Patch & Prep	Polymer Render	Quicksand	Armour Plus	Armour Plus
Sandcote	Hard Patch or Patch & Prep	Polymer Render	Sandcote	Armour Plus	Armour Plus
Santa Fe	Hard Patch or Patch & Prep	Polymer Render	Santa Fe	Armour Plus	Armour Plus
Santini	Hard Patch or Patch & Prep	Polymer Render	1mm Santini *	Armour Plus	Armour Plus
Sponge Finish	Hard Patch or Patch & Prep	Polymer Render	Polymer Render	Armour Plus	Armour Plus
Trowel-On	Hard Patch or Patch & Prep	Polymer Render	Trowel-On	Armour Plus	Armour Plus

* ROCKCOTE Finecote and Santini may require two applications to achieve 1mm dry film build

PERFORMANCE CODE 4

ROCKCOTE Performance Code 5 System is applicable for Fibre Cement Sheeting, due to the level of build required over the substrate

SYSTEM CHART

PERFORMANCE CODE 3

Finish	1st Step (set joints)	2nd Step	3rd Step	4th Step	5th Step
Finecote	Hard Patch or Patch & Prep	Polymer Render	1mm Finecote *	Armour Flex	n/a
Quicksand	Hard Patch or Patch & Prep	Polymer Render	Quicksand	Armour Flex	n/a
Sandcote	Hard Patch or Patch & Prep	Polymer Render	Sandcote	Armour Flex	n/a
Santa Fe	Hard Patch or Patch & Prep	Polymer Render	Santa Fe	Armour Flex	n/a
Santini	Hard Patch or Patch & Prep	Polymer Render	1mm Santini *	Armour Flex	n/a
Sponge Finish	Hard Patch or Patch & Prep	Polymer Render	Polymer Render	Armour Flex	n/a
Trowel-On	Hard Patch or Patch & Prep	Polymer Render	Trowel-On	Armour Flex	n/a

* ROCKCOTE Finecote and Santini may require two applications to achieve 1mm dry film build

PERFORMANCE CODE 2

Finish	1st Step (set joints)	2nd Step	3rd Step	4th Step	5th Step**
Finecote	Hard Patch or Patch & Prep	Polymer Render	Tinted Primer	1mm Finecote *	Repel or Clearcote
Quicksand (Option 1)	Hard Patch or Patch & Prep	Tinted Primer	Quicksand	Quicksand	Repel or Clearcote
Quicksand (Option 2)	Hard Patch or Patch & Prep	Polymer Render	Tinted Primer	Quicksand	Repel or Clearcote
Sandcote (Option 1)	Hard Patch or Patch & Prep	Tinted Primer	Sandcote	Sandcote	Repel or Clearcote
Sandcote (Option 2)	Hard Patch or Patch & Prep	Polymer Render	Tinted Primer	Sandcote	Repel or Clearcote
Santa Fe	Hard Patch or Patch & Prep	Polymer Render	Tinted Primer	Santa Fe	Repel or Clearcote
Santini	Hard Patch or Patch & Prep	Polymer Render	Tinted Primer	1mm Santini *	Repel or Clearcote
Trowel-On	Hard Patch or Patch & Prep	Polymer Render	Tinted Primer	Armour Plus	Repel or Clearcote

* ROCKCOTE Finecote and Santini may require two applications to achieve 1mm dry film build

** This step is optional. For extra durability, the application of ROCKCOTE Clearcote or ROCKCOTE Repel is recommended. ROCKCOTE Clearcote provides a satin finish, whilst ROCKCOTE Repel provides a natural look.

SYSTEM CHART

PERFORMANCE CODE 1					
Finish	1st Step (set joints)	2nd Step	3rd Step	4th Step	5th Step
Concote	Hard Patch or Patch & Prep	Polymer Render	Polymer Render	Tinted Primer	Concote
Render Paint Fine	Hard Patch or Patch & Prep	Polymer Render	Polymer Render	Render Paint Fine	Render Paint Fine
Render Paint Flat	Hard Patch or Patch & Prep	Polymer Render	Polymer Render	Render Paint Flat	Render Paint Flat
Santini	Hard Patch or Patch & Prep	Polymer Render	Primer	1mm Santini *	-
Torino	Hard Patch or Patch & Prep	Polymer Render	Polymer Render	Torino	Torino
Toscani	Hard Patch or Patch & Prep	Polymer Render	Polymer Render	Toscani	Toscani

* ROCKCOTE Finecote and Santini may require two applications to achieve 1mm dry film build

Indemnity

ROCKCOTE Enterprises Pty Ltd will not accept responsibility for any misuse of this product or if not applied by a skilled and experienced applicator and in accordance with our technical specifications. Due to our policy of continuing product improvement ROCKCOTE Enterprises Pty Ltd reserves the right to change these specifications without further notice.

