

SURFACE PREPARATION

- All surfaces should be clean and free from oil, dirt, dust or silicone.
- Remove any loose paint and contaminants from the surface prior to application of ROCKCOTE Polymer Render.

APPLICATION

- Apply ROCKCOTE Polymer Render using a metal hawk and trowel to the wall surface. Depending on the style of finish required, tools such as a plastic float will give a smooth rendered finish whilst the use of a sponge will give a sandy finish.
- Apply ROCKCOTE Polymer Render up to 4mm in thickness and bring to a floated finish using a timber or plastic float. Allow the surface to take up enough to lightly sponge the surface to a nice sandy finish and allow to dry for at least 24-48 hours before over coating.
- The application of ROCKCOTE Polymer Render is a specialist procedure and should only be carried out by a skilled and experienced applicator and in accordance with our technical specifications.

NB. Over painted walls with raked mortar joints, ROCKCOTE Reno Render is recommended in preference to ROCKCOTE Polymer Render to avoid telegraphing of the joints through to the finishing coat. Refer to ROCKCOTE Reno Render Technical Specification sheet.