

ROCKCOTE RENDER SYSTEM for Polymer Render over Fibre Cement Core Filled Systems - (including Ritek, Styrocon & AFS)

Surface Preparation

Install sheets strictly in accordance with manufacturers' specifications. Substrate must be clean and free of dust, dirt, oil, salt, mould or any other contamination. Patch, tape and set all recessed joints with 5 parts ROCKCOTE Hard Patch mixed with 1 part cement and 120gsm non-adhesive mesh tape.

Please refer to the relevant Technical Specification & Material Safety Data Sheet before application.

PERFORMANCE CODE 5

| Finish | 1st Step ** | 2nd Step | 3rd Step | 4th Step |
|---------------|----------------|----------------|----------------------|-------------|
| Armour Flex | Polymer Render | Polymer Render | Armour Flex, stipple | Armour Flex |
| Finecote | Polymer Render | 1mm Finecote * | Armour Plus | Armour Plus |
| Quicksand | Polymer Render | Quicksand | Armour Plus | Armour Plus |
| Sandcote | Polymer Render | Sandcote | Armour Plus | Armour Plus |
| Santa Fe | Polymer Render | Santa Fe | Armour Plus | Armour Plus |
| Santini | Polymer Render | 1mm Santini * | Armour Plus | Armour Plus |
| Sponge Finish | Polymer Render | Polymer Render | Armour Plus | Armour Plus |
| Trowel-On | Polymer Render | Trowel-On | Armour Plus | Armour Plus |

* ROCKCOTE Finecote and Santini may require two applications to achieve 1mm dry film build

** ROCKCOTE Keycote can be used in place of ROCKCOTE Polymer Render in Step 1.

PERFORMANCE CODE 4

ROCKCOTE Performance Code 5 System is applicable for coating fibre cement core filled substrates, due to the level of build required.

PERFORMANCE CODE 3

| Finish | 1st Step ** | 2nd Step | 3rd Step | 4th Step |
|---------------|----------------|----------------|-------------|----------|
| Finecote | Polymer Render | 1mm Finecote * | Armour Flex | n/a |
| Quicksand | Polymer Render | Quicksand | Armour Flex | n/a |
| Sandcote | Polymer Render | Sandcote | Armour Flex | n/a |
| Santa Fe | Polymer Render | Santa Fe | Armour Flex | n/a |
| Santini | Polymer Render | 1mm Santini * | Armour Flex | n/a |
| Sponge Finish | Polymer Render | Polymer Render | Armour Flex | n/a |
| Trowel-On | Polymer Render | Trowel-On | Armour Flex | n/a |

* ROCKCOTE Finecote and Santini may require two applications to achieve 1mm dry film build

** ROCKCOTE Keycote can be used in place of ROCKCOTE Polymer Render in Step 1.

SYSTEM CHART

PERFORMANCE CODE 2

| Finish | 1st Step ** | 2nd Step | 3rd Step | 4th Step*** |
|-----------|----------------|---------------|----------------|-----------------------------|
| Finecote | Polymer Render | Tinted Primer | 1mm Finecote * | ROCKCOTE Repel or Clearcote |
| Quicksand | Polymer Render | Tinted Primer | Quicksand | ROCKCOTE Repel or Clearcote |
| Sandcote | Polymer Render | Tinted Primer | Sandcote | ROCKCOTE Repel or Clearcote |
| Santa Fe | Polymer Render | Tinted Primer | Santa Fe | ROCKCOTE Repel or Clearcote |
| Santini | Polymer Render | Tinted Primer | 1mm Santini * | ROCKCOTE Repel or Clearcote |
| Trowel-On | Polymer Render | Tinted Primer | Trowel-On | ROCKCOTE Repel or Clearcote |

* ROCKCOTE Finecote and Santini may require two applications to achieve 1mm dry film build

** ROCKCOTE Keycote can be used in place of ROCKCOTE Polymer Render in Step 1

*** This step is optional. For extra durability, the application of ROCKCOTE Clearcote or ROCKCOTE Repel is recommended. ROCKCOTE Clearcote provides a satin finish, whilst ROCKCOTE Repel provides a natural look.

PERFORMANCE CODE 1

| Finish | 1st Step ** | 2nd Step | 3rd Step | 4th Step |
|-------------------|----------------|----------------|-------------------|-------------------|
| Concote | Polymer Render | Polymer Render | Tinted Primer | Concote |
| Render Paint Fine | Polymer Render | Polymer Render | Render Paint Fine | Render Paint Fine |
| Render Paint Flat | Polymer Render | Polymer Render | Render Paint Flat | Render Paint Flat |
| Santini | Polymer Render | Tinted Primer | 1mm Santini * | |
| Torino | Polymer Render | Polymer Render | Torino | Torino |
| Toscani | Polymer Render | Polymer Render | Toscani | Toscani |

* ROCKCOTE Finecote and Santini may require two applications to achieve 1mm dry film build

** ROCKCOTE Keycote can be used in place of ROCKCOTE Polymer Render in Step 1

Indemnity

ROCKCOTE Enterprises Pty Ltd will not accept responsibility for any misuse of this product or if not applied by a skilled and experienced applicator and in accordance with our technical specifications. Due to our policy of continuing product improvement ROCKCOTE Enterprises Pty Ltd reserves the right to change these specifications without further notice.