

ROCKCOTE SYSTEM CHART for Acrylic Render over Hebel Power Panel

Surface Preparation

Substrate must be clean and free of dust, dirt, oil, salt, mould or any other contamination. Seal with one coat of ROCKCOTE Acrybond mixed 50/50 with water, to control absorption rate and improve adhesion.

NOTE:

These systems are dependant on correct & straight installation of cladding and the Level of Finish required.

Please refer to the relevant Technical Specifications & Material Safety Data Sheets before applying ROCKCOTE products.

Please refer to the relevant Technical Specification & Material Safety Data Sheet before application.

PERFORMANCE CODE 5

Finish	1st Step	2nd Step	3rd Step	4th Step
Finecote	Polymer Render	1mm Finecote *	Armour Plus	Armour Plus
Quicksand	Polymer Render	Quicksand	Armour Plus	Armour Plus
Sandcote	Polymer Render	Sandcote	Armour Plus	Armour Plus
Santa Fe	Polymer Render	Santa Fe	Armour Plus	Armour Plus
Santini	Polymer Render	1mm Santini *	Armour Plus	Armour Plus
Sponge Finish	Polymer Render	Polymer Render	Armour Plus	Armour Plus
Trowel On (1, 1.5, 2 & 3mm)	Polymer Render	Trowel On (1, 1.5, 2 & 3mm)	Armour Plus	Armour Plus
Trowel-On (2mm & 3mm only)	Texprime	Trowel-On (2mm & 3mm only)	Armour Plus	Armour Plus

*ROCKCOTE Finecote & Santini may require two applications to achieve 1mm dry film build.

PERFORMANCE CODE 4

Finish	1st Step	2nd Step	3rd Step	4th Step
Armour Flex (Low profile)	Polymer Render	Armour Flex (stipple)	Armour Flex	n/a
Concote (Medium profile)	Polymer Render	Concote (medium texture roller)	Armour Flex	Armour Flex

SYSTEM CHART

PERFORMANCE CODE 3

Finish	1st Step	2nd Step	3rd Step	4th Step
Finecote	Polymer Render	1mm Finecote *	Armour Flex	n/a
Quicksand	Polymer Render	Quicksand	Armour Flex	n/a
Sandcote	Polymer Render	Sandcote	Armour Flex	n/a
Santa Fe	Polymer Render	Santa Fe	Armour Flex	n/a
Santini (Option 1)	Texprime	2mm Santini *	Armour Flex	n/a
Santini (Option 2)	Polymer Render	1mm Santini *	Armour Flex	n/a
Sponge Finish	Polymer Render	Polymer Render	Armour Flex	n/a
Trowel-On (1, 1.5, 2 & 3mm)	Polymer Render	Trowel-On (1, 1.5, 2 & 3mm)	Armour Flex	n/a
Trowel-On (2mm & 3mm only)	Texprime	Trowel-On (2mm & 3mm only)	Armour Flex	n/a

*ROCKCOTE Finecote & Santini may require two applications to achieve 1mm dry film build.

PERFORMANCE CODE 2

Finish	1st Step	2nd Step	3rd Step	4th Step**
Finecote	Polymer Render	Tinted Primer	1mm Finecote *	Clearcote or Repel
Quicksand (Option 1)	Quicksand	Quicksand	Clearcote or Repel**	n/a
Quicksand (Option 2)	Polymer Render	Tinted Primer	Quicksand	Clearcote or Repel
Sandcote (Option 1)	Sandcote	Sandcote	Clearcote or Repel**	n/a
Sandcote (Option 2)	Polymer Render	Tinted Primer	Sandcote	Clearcote or Repel
Santa Fe	Polymer Render	Tinted Primer	Santa Fe	Clearcote or Repel
Santini	Polymer Render	Tinted Primer	1mm Santini *	Clearcote or Repel
Trowel On (1, 1.5, 2 & 3mm)	Polymer Render	Tinted Primer	Trowel On (1, 1.5, 2 & 3mm)	Clearcote or Repel

*ROCKCOTE Finecote & Santini may require two applications to achieve 1mm dry film build.

** Step 4 is optional. For extra durability, the application of ROCKCOTE Clearcote or ROCKCOTE Repel is recommended. ROCKCOTE Clearcote provides a satin finish, whilst ROCKCOTE Repel provides a natural look.

SYSTEM CHART

ROCKCOTE
RENDER • TEXTURE • PAINT

Page 3 of 3 Updated 6th April, 2010

Acrylic Render over Hebel Power Panel

PERFORMANCE CODE 1				
Finish	1st Step	2nd Step	3rd Step	4th Step
Santini	Texprime	1mm Santini*	1mm Santini*	n/a
Render Paint Flat	Polymer Render	Polymer Render	Render Paint Flat	Render Paint Flat
Toscani	Polymer Render	Polymer Render	Toscani	Toscani
Render Paint Fine	Polymer Render	Polymer Render	Render Paint Fine	Render Paint Fine
Torino	Polymer Render	Polymer Render	Torino	Torino
Concote	Polymer Render	Polymer Render	Tinted Primer	Concote

*ROCKCOTE Finecote & Santini may require two applications to achieve 1mm dry film build.

**For extra durability, the application of ROCKCOTE Clearcote or ROCKCOTE Repel is recommended. ROCKCOTE Clearcote provides a satin finish, whilst ROCKCOTE Repel provides a natural look.

Indemnity

ROCKCOTE Enterprises Pty Ltd will not accept responsibility for any misuse of this product or if not applied by a skilled and experienced applicator and in accordance with our technical specifications. Due to our policy of continuing product improvement ROCKCOTE Enterprises Pty Ltd reserves the right to change these specifications without further notice.

