

### ROCKCOTE RENDER SYSTEMS FOR BRICK AND BLOCK SUBSTRATES

#### Surface Preparation

Remove all deleterious and loose materials and leave surfaces clean and free of dust, oil, dirt, mould or any other contamination. ROCKCOTE Keycote should be applied to the brick or block substrate if the surface is smooth and has very little or excessive absorption rates.

#### Application of ROCKCOTE Keycote

Moisten the substrate. Once the shine has gone off the surface, trowel or bag ROCKCOTE Keycote over the entire surface to a thickness of 1-2mm, leaving the surface rough to provide suitable key for render application. Substrate must be wet down to assist with correct cement hydration and bonding.

Please refer to the relevant Technical Specifications & Material Safety Data Sheets before applying ROCKCOTE products.

#### PERFORMANCE CODE 5

Finish	1st Step	2nd Step	3rd Step	4th Step
Sponge Finish	ROCKCOTE Render	Polymer Render	Armour Plus	Armour Plus
Santa Fe	ROCKCOTE Render	Santa Fe	Armour Plus	Armour Plus
Finecote	ROCKCOTE Render	1mm Finecote *	Armour Plus	Armour Plus
Sandcote Plus	ROCKCOTE Render	Sandcote Plus	Armour Plus	Armour Plus
Trowel-On	ROCKCOTE Render	Trowel On	Armour Plus	Armour Plus
Santini	ROCKCOTE Render	1mm Santini *	Armour Plus	Armour Plus
Quicksand	ROCKCOTE Render	Quicksand	Armour Plus	Armour Plus

\* Finecote and Santini may require two applications to achieve 1mm dry film build.

#### PERFORMANCE CODE 4

Finish	1st Step	2nd Step	3rd Step	4th Step
Armour Flex (Low profile)	ROCKCOTE Render	Armour Flex (stipple)	Armour Flex	n/a
Concote (Medium profile)	ROCKCOTE Render	Concote (medium texture roller)	Armour Flex	Armour Flex

#### PERFORMANCE CODE 3

Finish	1st Step	2nd Step	3rd Step
Sponge Finish	ROCKCOTE Render	Polymer Render	Armour Flex
Sandcote Plus	ROCKCOTE Render	Sandcote Plus	Armour Flex
Santa Fe	ROCKCOTE Render	Santa Fe	Armour Flex
Finecote	ROCKCOTE Render	1mm Finecote *	Armour Flex
Trowel On	ROCKCOTE Render	Trowel On	Armour Flex
Santini	ROCKCOTE Render	1mm Santini *	Armour Flex
Quicksand	ROCKCOTE Render	Quicksand	Armour Flex

\* Finecote and Santini may require two applications to achieve 1mm dry film build.

PERFORMANCE CODE 2				
Finish	1st Step	2nd Step	3rd Step	4th Step **
Sandcote Plus	ROCKCOTE Render	Tinted Primer	Sandcote Plus	Clearcote or Rockcote Repel
Santa Fe	ROCKCOTE Render	Tinted Primer	Santa Fe	Clearcote or Rockcote Repel
Finecote	ROCKCOTE Render	Tinted Primer	1mm Finecote *	Clearcote or Rockcote Repel
Trowel-On	ROCKCOTE Render	Tinted Primer	Trowel-On	Clearcote or Rockcote Repel
Santini	ROCKCOTE Render	Tinted Primer	1mm Santini *	Clearcote or Rockcote Repel
Quicksand	ROCKCOTE Render	Tinted Primer	Quicksand	Clearcote or Rockcote Repel

\* Finecote and Santini may require two applications to achieve 1mm dry film build.

\*\* Step 4 is optional. For extra durability, the application of ROCKCOTE Clearcote or ROCKCOTE Repel is recommended. ROCKCOTE Clearcote provides a satin finish, whilst ROCKCOTE Repel provides a natural look.

PERFORMANCE CODE 1				
Finish	1st Step	2nd Step	3rd Step	4th Step
Santini	Anti-Eflorescent Primer	Santini	-	-
Render Paint	ROCKCOTE Render	Render Paint	Render Paint	-
Toscani	ROCKCOTE Render	Toscani	Toscani	-
Render Paint Fine	ROCKCOTE Render	Render Paint Fine	Render Paint Fine	-
Torino	ROCKCOTE Render	Torino	Torino	-
Concote	Anti-Eflorescent Primer	Concote	-	-
Fast Float Finish Medium	ROCKCOTE Render	Fast Float Finish Medium	Armour Plus	Armour Plus
Fast Float Finish Fine	ROCKCOTE Render	Fast Float Finish Fine	Armour Plus	Armour Plus
Sponge Finish	ROCKCOTE Render	Armour Plus	Armour Plus	-

### Indemnity

ROCKCOTE Enterprises Pty Ltd will not accept responsibility for any misuse of this product or if not applied by a skilled and experienced applicator and in accordance with our technical specifications. Due to our policy of continuing product improvement