

ROCKCOTE RENDER SYSTEMS FOR Cement Render over Hebel Power Panel

Surface Preparation

Substrate must be clean and free of dust, dirt, oil, salt, mould or any other contamination.

Seal with one coat of ROCKCOTE Acrybond mixed 50/50 with water, to control absorption rate and improve adhesion.

NB: Please refer to the relevant Technical Specifications & Material Safety Data Sheets before applying ROCKCOTE products.

PERFORMANCE CODE 5

Finish	1st Step	2nd Step	3rd Step	4th Step
Sponge Finish	ROCKCOTE Cement Render	Polymer Render	Armour Plus	Armour Plus
Santa Fe	ROCKCOTE Cement Render	Santa Fe	Armour Plus	Armour Plus
Finecote	ROCKCOTE Cement Render	1mm Finecote *	Armour Plus	Armour Plus
Sandcote	ROCKCOTE Cement Render	Sandcote	Armour Plus	Armour Plus
Trowel On	ROCKCOTE Cement Render	Trowel On	Armour Plus	Armour Plus
Santini	ROCKCOTE Cement Render	1mm Santini *	Armour Plus	Armour Plus
Quicksand	ROCKCOTE Cement Render	Quicksand	Armour Plus	Armour Plus
Armour Flex	ROCKCOTE Cement Render	Polymer Render	Armour Flex Stipple	Armour Flex

*ROCKCOTE Finecote & Santini may require two applications to achieve 1mm dry film build.

PERFORMANCE CODE 4

Finish	1st Step	2nd Step	3rd Step	4th Step
Armour Flex (Low profile)	ROCKCOTE Render	Armour Flex (stipple)	Armour Flex	n/a
Concote (Medium profile)	ROCKCOTE Render	Concote (medium texture roller)	Armour Flex	Armour Flex

PERFORMANCE CODE 3				
Finish	1st Step	2nd Step	3rd Step	4th Step
Sponge Finish	ROCKCOTE Cement Render	Polymer Render	Armour Flex	n/a
Sandcote	ROCKCOTE Cement Render	Sandcote	Armour Flex	n/a
Santa Fe	ROCKCOTE Cement Render	Santa Fe	Armour Flex	n/a
Finecote	ROCKCOTE Cement Render	1mm Finecote *	Armour Flex	n/a
Trowel On	ROCKCOTE Cement Render	Trowel On	Armour Flex	n/a
Santini	ROCKCOTE Cement Render	1mm Santini *	Armour Flex	n/a
Quicksand	ROCKCOTE Cement Render	Quicksand	Armour Flex	n/a

*ROCKCOTE Finecote & Santini may require two applications to achieve 1mm dry film build.

PERFORMANCE CODE 2				
Finish	1st Step	2nd Step	3rd Step	4th Step**
Sandcote	ROCKCOTE Cement Render	Tinted Primer	Sandcote	Clearcote or ROCKCOTE Repel
Santa Fe	ROCKCOTE Cement Render	Tinted Primer	Santa Fe	Clearcote or ROCKCOTE Repel
Finecote	ROCKCOTE Cement Render	Tinted Primer	1mm Finecote *	Clearcote or ROCKCOTE Repel
Trowel On	ROCKCOTE Cement Render	Tinted Primer	Trowel On	Clearcote or ROCKCOTE Repel
Santini	ROCKCOTE Cement Render	Tinted Primer	1mm Santini *	Clearcote or ROCKCOTE Repel
Quicksand	ROCKCOTE Cement Render	Tinted Primer	Quicksand	Clearcote or ROCKCOTE Repel

*ROCKCOTE Finecote & Santini may require two applications to achieve 1mm dry film build.

** Step 4 is optional. For extra durability, the application of ROCKCOTE Clearcote or ROCKCOTE Repel is recommended. ROCKCOTE Clearcote provides a satin finish, whilst ROCKCOTE Repel provides a natural look.

PERFORMANCE CODE 1				
Finish	1st Step	2nd Step	3rd Step	4th Step
Santini	ROCKCOTE Cement Render	Primer	1mm Santini*	
Render Paint Flat	ROCKCOTE Cement Render	Render Paint Flat	Render Paint Flat	
Toscani	ROCKCOTE Cement Render	Toscani	Toscani	
Render Paint Fine	ROCKCOTE Cement Render	Render Paint Fine	Render Paint Fine	
Torino	ROCKCOTE Cement Render	Torino	Torino	
Concote	ROCKCOTE Cement Render	Tinted Primer	Concote	
Fast Float Finish, Medium	ROCKCOTE Cement Render	Fast Float Medium	Armour Plus	Armour Plus
Fast Float Finish, Fine	ROCKCOTE Cement Render	Fast Float Fine	Armour Plus	Armour Plus
Sponge Finish	ROCKCOTE Cement Render	Armour Plus	Armour Plus	

*ROCKCOTE Finecote & Santini may require two applications to achieve 1mm dry film build.

Indemnity

ROCKCOTE Enterprises Pty Ltd will not accept responsibility for any misuse of this product or if not applied by a skilled and experienced applicator and in accordance with our technical specifications. Due to our policy of continuing product improvement ROCKCOTE Enterprises Pty Ltd reserves the right to change these specifications without further notice.