

SYSTEM CHART

ROCKCOTE RENDER SYSTEMS for Site Mix Render

Surface Preparation

Surface must not be powdery under touch. New cement render should be cured for 28 days. Remove all deleterious and loose materials and leave surfaces clean and free of dust, oil, dirt, mould or any other contamination. Repair any cracks, holes and other patches. Prime with ROCKCOTE Anti Efflorescence Primer [AE Primer]

Please refer to the relevant Technical Specification & Material Safety Data Sheet before application.

PERFORMANCE CODE 5

Finish	1st Step	2nd Step	3rd Step	4th Step	5th Step
Finecote	AE Primer	1mm Finecote *	Armour Plus	Armour Plus	n/a
Quicksand	AE Primer	Quicksand	Armour Plus	Armour Plus	n/a
Sandcote	AE Primer	Sandcote	Armour Plus	Armour Plus	n/a
Santa Fe	AE Primer	Santa Fe	Armour Plus	Armour Plus	n/a
Santini	AE Primer	1mm Santini *	Armour Plus	Armour Plus	n/a
Sponge Finish	AE Primer	Polymer Render	Armour Plus	Armour Plus	n/a
Trowel-On	AE Primer	Trowel-On	Armour Plus	Armour Plus	n/a

* ROCKCOTE Finecote and Santini may require two applications to achieve 1mm dry film build

PERFORMANCE CODE 4

Finish	1st Step	2nd Step	3rd Step	4th Step	5th Step
Armour Flex Low Profile	AE Primer	Armour Flex (stipple)	Armour Flex	n/a	n/a
Concote Medium Profile	AE Primer	Concote (medium texture roller)	Armour Flex	Armour Flex	n/a

PERFORMANCE CODE 3

Finish	1st Step	2nd Step	3rd Step	4th Step	5th Step
Finecote	AE Primer	1mm Finecote *	Armour Flex	n/a	n/a
Quicksand	AE Primer	Quicksand	Armour Flex	n/a	n/a
Sandcote	AE Primer	Sandcote	Armour Flex	n/a	n/a
Santa Fe	AE Primer	Santa Fe	Armour Flex	n/a	n/a
Santini	AE Primer	1mm Santini *	Armour Flex	n/a	n/a
Sponge Finish	AE Primer	Polymer Render	Armour Flex	n/a	n/a
Trowel On	AE Primer	Trowel On	Armour Flex	n/a	n/a

* ROCKCOTE Finecote and Santini may require two applications to achieve 1mm dry film build

SYSTEM CHART

PERFORMANCE CODE 2

Finish	1st Step	2nd Step	3rd Step **	4th Step	5th Step
Finecote	AE Primer	1mm Finecote *	ROCKCOTE Repel or Clearcote	n/a	n/a
Sandcote	AE Primer	Sandcote	ROCKCOTE Repel or Clearcote	n/a	n/a
Santa Fe	AE Primer	Santa Fe	ROCKCOTE Repel or Clearcote	n/a	n/a
Trowel On	AE Primer	Trowel On	ROCKCOTE Repel or Clearcote	n/a	n/a
Quicksand	AE Primer	Quicksand	ROCKCOTE Repel or Clearcote	n/a	n/a

* ROCKCOTE Finecote and Santini may require two applications to achieve 1mm dry film build

** This step is optional. For extra durability, the application of ROCKCOTE Clearcote or ROCKCOTE Repel is recommended. ROCKCOTE Clearcote provides a satin finish, whilst ROCKCOTE Repel provides a natural look.

PERFORMANCE CODE 1

Finish	1st Step	2nd Step	3rd Step	4th Step	5th Step **
Armour Plus	AE Primer	Armour Plus	Armour Plus	n/a	n/a
Concote	AE Primer	Concote	n/a	n/a	n/a
Fast Float Finish, Medium	Fast Float Finish, Medium	AE Primer	Armour Plus	Armour Plus	n/a
Fast Float Finish, Fine	Fast Float Finish, Fine	AE Primer	Armour Plus	Armour Plus	n/a
Render Paint Fine	AE Primer	Render Paint Fine	Render Paint Fine	n/a	n/a
Render Paint Flat	AE Primer	Render Paint Flat	Render Paint Flat	n/a	n/a
Santini	AE Primer	Santini *	n/a	n/a	n/a
Torino	AE Primer	Torino	Torino	n/a	n/a
Toscani	AE Primer	Toscani	Toscani	n/a	n/a

* ROCKCOTE Finecote and Santini may require two applications to achieve 1mm dry film build

Indemnity

ROCKCOTE Enterprises Pty Ltd will not accept responsibility for any misuse of this product or if not applied by a skilled and experienced applicator and in accordance with our technical specifications. Due to our policy of continuing product improvement ROCKCOTE Enterprises Pty Ltd reserves the right to change these specifications without further notice.

