

ROCKCOTE COMPONENTS REQUIRED FOR BUSHFIRE ATTACK LEVEL (BAL) 29 AREAS

1. ROCKCOTE PM 100 (10mm; +/- 1mm)
2. ROCKCOTE 160gsm Reinforcing Mesh Embedded into ROCKCOTE PM 100
3. ROCKCOTE Sandcote (1mm)
4. ROCKCOTE Armour Flex (2 coats)

NOTE: For BAL 29 Certification **EACH** ROCKCOTE component must be used at the required film build and cannot be substituted with **ANY** other product.

NOTE: ROCKCOTE Hi Op Primer can be used in-between ROCKCOTE Sandcote and Armour Flex for large walls exposed to side light conditions.

SCHEDULE OF COMPLETE WALL SYSTEM COMPONENTS FOR (BAL) 29 AREAS

1. 75mm NRG Greenboard 2500 x 1200
2. NRG 125mm 10 gauge bugle head screws
3. NRG Greenboard 40mm Washers
4. 30mm x 25mm NRG Battens
5. Sisalation: Extra Heavy Duty Wall Wrap (Breather)
6. 6mm PVC Render Beads
7. Bostik No More Nails
8. Bostik Fireban Sealant
9. ROCKCOTE Reinforced Render System
10. ROCKCOTE PM 100 (10mm; +/- 1mm)
11. ROCKCOTE 160gsm Reinforcing Mesh Embedded into ROCKCOTE PM 100
12. ROCKCOTE Sandcote (1mm)
13. ROCKCOTE Armour Flex (2 coats)

NOTE: ROCKCOTE Hi Op Primer can be used in-between ROCKCOTE Sandcote and Armour Flex for large walls exposed to side light conditions.

Points 1-8 inclusive are to be fitted as per NRG Greenboard Fixing Manual.

Points 9-13 inclusive are to be followed as per ROCKCOTE REINFORCED RENDER SYSTEM (Available at www.rockcote.com.au/tech-info).

Exova Warringtonfire Test Report:

Full scale bushfire external wall test of a framed wall system in accordance with AS1530.8.1-2007. EWFA Report No. 2581501.1

ROCKCOTE[®]
COLOURED RENDERS • PAINTED FINISHES
Naturally Beautiful